



Nature's Edge Vinyl Plank – Installation Guide

Installation

1. Surface Preparation;
Subfloor (wood or concrete) must be structurally sound, clean, smooth, dry, free from dust, dirt, wax, grease, and/or any other foreign material that would interfere with a good bond.
2. DO NOT USE adhesives where moisture is present in concrete or wood-type subfloors. Moisture may retard or prevent adhesive from setting.

Installation Guide

1. Nature's Edge planks and adhesive must be conditioned at room temperature, minimum 65°F for 24 hours before and 24 hours after installation.
2. Spread adhesive with a 1/16" x 16" x 1/16" square notch trowel.
3. Apply adhesive to subfloor according to the instructions on the container.
4. Spread adhesives in small areas to avoid letting the adhesive dry too much before you have finished laying your plank.
5. For planks use the wet set installation instructions.
6. Roll each section immediately upon completing with a 100 pound three section roller.
7. Re-roll the entire floor after one or two hours.
8. If you do not have access to a roller, then use a rolling pin and your body weight.
9. Do not wash or treat the floor for a minimum of 48 hours after installation.